

Retrieving your messages

In Japan: Dial 1417 then press the blue phone key.

In Korea: Dial +81 90 4444 0141 then press the blue phone key. After a 10 second (approx) Japanese message and beep, input your mobile number and then press #. After a second message and beep, input the PIN number 1020. Then follow the English voice prompts.

After listening to your messages

Press 9 to delete message

Press 1 to listen to the message again

Press 2 to save your message

To navigate through more than one message, use the Fast Forward # key or Fast Rewind * key and any key to Pause, other than the 'exit' or 'off' key.

When leaving VoiceMail messages whilst the GP user is in Japan, the caller should dial the mobile number of the GP user. If the phone is switched off, out of coverage or busy, the caller will be diverted to an answering service.

To leave a message, follow the English voice prompts.

When leaving VoiceMail messages whilst the GP user is in Korea, the caller should dial: +81 90 4444 0141. After the first Japanese message and beep, the caller should input the user's mobile number, then press #.

After the second Japanese message and beep, the caller should leave any message and then end the call.

To adjust the volume

Press the up and down arrows on the scroll pad to increase and decrease volume levels or press the arrow buttons on the side of the handset.

To adjust the 'ringer volume', you need to access F21. To do this, select F21 using the left hand key, then use the scroll pad to increase and decrease the 'ringer volume'.

24 Hour Customer Service

The customer service teams are available
24 hours a day, 7 days a week:

Cellhire UK	+ 44 1904 610610
Cellhire USA	+ 1 214 765 7399
Cellhire France	+ 33 1 41 43 79 40
Cellhire Australia	+ 61 2 9286 9494
Cellhire International	+ 44 1904 610610

www.cellhire.com



Global Passport

Your handset for
Japan & Korea



User Instructions



Thank you for renting your GP phone from Cellhire



A single Global Passport phone will enable you to make and receive domestic and international calls within Japan and South Korea.

Your Global Passport handset is preset to 'Japan mode' which will allow you to make calls for your arrival in Japan. However, if you intend to use your handset in Korea you will need to set the 'country mode' and 'system channel'.

To set the system channel

- Press F (using silver key on left) then 9 4.
- Select the country mode you require by pressing the down arrow on the scroll pad.
- Then select SYSTEM by pressing silver button on the right.
- Select 'A' system by pressing Menu OK twice.

To set the country code

- Press F using silver key on left then 9 4.
- Select the country mode you require by pressing the down arrow on the scroll pad.
- Press MENU OK twice.

To switch the phone on

Press and hold the red phone key until the phone powers on, (a display will appear on the screen). Repeat to switch off.

To make a call

To make a domestic call in Japan

Dial city/area code, phone number. Press blue phone key.
E.g. 03 1234 5678

To make an international call in Japan

Dial 005345, country code, area/city code, then phone number. Press blue phone key.
E.g. 005345 82 2 1234 5678

To make a domestic call in Korea

Dial phone number. Press blue phone key.
E.g. 02 1234 5678

To make an international call in Korea

To call Japan: Dial 002, country code, area code, then phone number. Press blue phone key.
E.g. 002 81 3 1234 5678

To call other countries: Dial 002, country code, area code then, phone number. Press blue phone key.

E.g. 002 44 113 1234567

Important Note: When making international calls, the first 0 of the area code or mobile number should be omitted when dialling.

To receive calls

From Japan

The calling party should dial your telephone number and press the send key.
E.g. 090 1234 5678

From any country other than Japan

The calling party should dial the international access code followed by 81, then the phone number.
E.g. from UK: 00 81 90 1234 5678

To receive a call from another GP handset

The calling party should:

From Japan: Dial GP number then send the call
From any other country: +81 then GP number.
E.g. +81 90 1234 5678

VoiceMail

English VoiceMail is available in Japan and Korea.

Message notification

In Japan: When you receive a VoiceMail message, an envelope symbol will appear on the phone display.

In Korea: You will need to dial into the VoiceMail system periodically to check for messages. (See next page).